



Slide and listen.

Please take the time to carefully read and follow the Important Safety Instructions, Warranty and Contact Information.

This product was developed under the philosophy of Open Source Design and Digital Manufacturing. All the construction files are open (Creative Commons licensed) for the people to work on top of them, modify and share with the community. This product can be completely manufactured (hardware & software) within a FabLab using tools like a Laser-cutting, 3D printer, milling machine, etc..

Our ambition is to bring the quality of Italian creativity to modern innovations of contemporary goods and new approaches to common objects and habits, blending innovative experiences and digital manufacturing techniques and custom production.

Congratulations for choosing the **OPEN MIRROR** - the interactive mirror that control your music world. Far from charge your iPod / iPhone, the system let you control your favorite music through an intuitive and touch-free interface.

THANK YOU FOR YOUR PURCHASE



IMPORTANT SAFETY INSTRUCTIONS

1. Read these instructions – for all components before using this product.
2. Keep these instructions – for future reference.
3. Heed all warnings – on the product and in the owner’s guide.
4. Follow all instructions.
5. Clean only with a dry cloth. Unplug this product from the wall outlet before cleaning.
6. Do not install near any heat sources, such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
7. Only use attachments/accessories specified by the manufacturer.
8. Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
9. Unplug this apparatus during lightning storms or when unused for long periods of time – to prevent damage to this product.
10. Refer all servicing to qualified service personnel.

Servicing is required when the apparatus has been damaged in any way: such as power supply cord or plug is damaged; liquid has been spilled or objects have fallen into the apparatus; the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped – Do not attempt to service this product yourself. Opening or removing covers may expose you to dangerous voltages or other hazards.

11. To prevent risk of fire or electric shock, avoid overloading wall outlets, extension cords, or integral convenience receptacles.

OPENMIRROR and the **OPEN MIRROR** design are registered trademarks of **Digital Habits**.

iPod is a trademark of Apple Inc., registered in the U.S. and other countries. iPhone is a trademark of Apple Inc.

Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards.

*iPhone is not included.

This product conforms to all EU Directive requirements as applicable by law. The complete Declaration of Conformity can be found at www.digitalhabits.it



CUSTOMER SERVICE

For questions about the **OPEN MIRROR**, contact us through e-mail at support@digitalhabits.it.

TECHNICAL INFORMATION

Power supply rating	System size and weight
Input: 220-240V 50-60Hz	41 cm x 55.4 cm x 6.2 cm
Output: 15V, 1.2A	with dock closed
	3.5 Kg. without Packaging

COMPATIBILITY

The **OPEN MIRROR** is compatible with all iPhone and most iPod models. For iPhone 5 with Lightning connector, it's necessary a Lightning to 30-pin Adapter.

Not compatible with 3rd generation with dock connector (iPod has four buttons above the touch wheel).

WARNINGS and CAUTIONS

- To reduce the risk of fire or electric shock, do not expose this product to rain or moisture. The product shall not be exposed to dripping or splashing, and objects filled with liquids, such as vases, shall not be placed on or near the product. As with any electronic products, use care not to spill liquids into any part of the product. Liquids can cause a failure and/or a fire hazard.
- The power supply must be used indoors only. It is neither designed nor tested for use outdoors, in recreation vehicles, or on boats.
- The modifications that you make of this product may compromise safety, regulatory compliance, and system performance, and will void the warranty. Do it under your own risk.

TROUBLESHOOTING

iPod or iPhone does not dock properly or will not charge:

- Check for obstructions in dock connectors and reseat device.
- Remove your iPod or iPhone case.

No sound:

- Make sure system has AC power.
- Turn system volume up and ensure source is playing.
- Remove iPod or iPhone from dock for 5 seconds, then firmly reseat it.
- Unplug power cord for 1 minute, then plug back in. This resets the system.

WHAT'S INSIDE THE BOX

DIGITAL HABIT(S)

OPEN MIRROR

Digitally crafted by DIGITAL HABIT(S)

OWNER'S GUIDE



INTERACTION AND MUSIC

OPEN SOURCE DESIGN

NATURAL INTERFACE

DIGITAL FABRICATION

1

- Drill 2 holes separated by 22cm (horizontal). Use a 6 mm drill.
- Fix the OPEN MIRROR to the wall with the 2 screws provided.

2

- Slide the lower part of the Main Body and route the cable behind.
- Verify that the mirror is OFF.
- Plug the power source.

3

- Unbox the Upper Mirror
- Place the Upper Mirror **inserting** the upper 3 pins into the Main Body holes.

4

- Turn ON the OPEN MIRROR
[The Gap in the middle will light up once you turn it on]

5

- Slide & Connect your iPod / iPhone.
- Play your favorite music, raise the volume and Enjoy!

USING THE OPEN MIRROR

PLAY | PAUSE

▶ | ||
Place and Remove your hand under **Sensor A**

CONTROL / SENSORS

VOLUME

VOLUME DOWN
Place and hold your hand under **Sensor B**

VOLUME UP
Place and hold your hand under **Sensor C**

SKIP SONG

◀◀
BACKWARD
Swap your hand between **Sensors C & B**

FORWARD

▶▶
FORWARD
Swap your hand between **Sensors B & C**

